



5311

Access Control

Reader Interface

The 5311 Reader interface allows Cotag Technology Reading Heads to integrate into non Cotag systems, typically Access Control and other similar applications. Popular data interfaces ensure easy integration with most host systems.

*For enhanced reader functionality, see the 5411 Multi-Function Reader.

Operating parameters, interface requirements, Distributor Code and Secondary Code can all be easily configured using configuration Tags supplied by the distributor. LEDs & horn may be driven internally or externally.

Simple installation, easy configuration. Reverse polarity protection using self-resetting fuse. Delivered without any configuration.

Onboard interface library supports popular clock&data and Wiegand interfaces. Interface set by using a configuration card. Distributor code/secondary code set by presenting a Cotag card containing the valid distributor code/secondary code.

Technical data

Operating voltage	12 V DC
Current consumption	350 mA
Operating temperature	0 to +50 °C
Dimensions (W x H x D)	110 x 195 x 40 mm

Details for ordering

Type	Part no	Designation	Weight
5311	GBI:52-110	5311 Reader Interface	0.4 kg

Issued by
Siemens AB
Security Products
International Headquarters
Englundavägen 7
SE-171 24 Solna
Tel. +46 8 629 0300

© 2011 Copyright by Siemens AB

Data and design subject to change without notice.
Supply subject to availability.

www.siemens.com/securityproducts

Document no. **A6V10330073**
Edition 05.2011