


020-742

**IDR-CME mimic expansion board kit**



Provides 16 LEDs or relays outputs. Up to 9 expansion boards can be daisy chained. Requires 020-741 IDR-CM Mimic main board. For use with "local zones".

020-573

**IDR-M mimic control PCA kit**



Compatible with NF30/50 and NF3000 Panels. Mimic control PCA Kit. Supports up to 8 Mimic Drivers. Requires ext. 24VDC Power source and min. one 020-574. Use the mimic driver configuration tool kit (020-613). For use with "network zones".

020-574

**IDR-MD mimic driver and terminal PCA kit**



Provides 64 LEDs or relays outputs and 8 inputs. Up to 8 Mimic Drivers can be daisy chained. Requires Mimic Control PCA Kit and external 24VDC. Power source. For use with "network zones".

ITS-BOX

**RS232-TCP/IP device converter**



ITS-BOX provides a hassle-free and inexpensive way to add Ethernet connectivity to virtually any device with a serial interface. ITS-BOX creates a fully transparent serial connection to existing PC-based software applications, making it possible to remotely connect to equipment already in the field as if it were connected to a local PC serial port. Additionally, ITS-BOX is equipped with a built-in web server that allows users the flexibility to access, control, and configure equipment using a standard web browser.

