SIEMENS 4<sup>315</sup>



ACVATIX™

# Combi valves PN 16 with VPF43.. flanged connections

Pressure Independent Combi Valves

- With integrated pressure differential controller
- Valve body made of gray cast iron GJL-250
- DN 50 150
- Volumetric flow 15 to 195 m<sup>3</sup>/h nominal, with presetting
- Equipped with pressure test points P/T
- Can be equipped with SAX..P.., SAV..P.. or SQV..P.. electromotoric actuators

#### Use

- For use in heating, ventilating and air conditioning systems, district heating, as a control valve.
- For closed circuits.

#### Type summary

					· ·		
				H <sub>100</sub>	V <sub>min</sub>	V <sub>100</sub>	$\Delta p_{\text{min}}$
	Product number	Stock number	DN	[mm]	[m <sup>3</sup> /h]	[m <sup>3</sup> /h]	[kPa]
Standard flow rate	VPF43.50F16	S55266-V100	50		2.3	15	
	VPF43.65F24	S55266-V102	65	20	4.4	25	
	VPF43.80F35	S55266-V104	80		5.3	34	
	VPF43. 100F70	S55266-V106	100	40	12.1	68	35
	VPF43. 125F110	S55266-V108	125		18.5	110	
	VPF43. 150F160	S55266-V110	150	43	25.6	148	
High flow rate	VPF43.50F25	S55266-V101	50		4.3	25	
	VPF43.65F35	S55266-V103	65	20	6	35	70

VPF43.80F45 S55266-V105 80 7 43 14.8 VPF43. 100F90 S55266-V107 90 75 100 40 VPF43. 125F135 S55266-V109 125 23 135 53 VPF43. 150F200 S55266-V111 150 43 195 65

DN = nominal size

 $H_{100}$  = nominal stroke

 $\dot{V}_{100}$  = volumetric flow through fully open valve (H<sub>100</sub>)

 $\dot{V}_{min}$  = smallest presettable volumetric flow through fully open valve (H<sub>100</sub>)

 $\Delta p_{min}$  = minimum differential pressure required across the valve's control path, so that the difference pressure regulator works reliably

### Ordering

Example:	Product number	Stock number	Designation
	VPF43.65F24	S55266-V102	Combi valve PN 16 with flanged connections

Delivery Combi valves, actuators and accessories are packed and supplied separately.

The valves are supplied without counter-flanges and without flange gaskets.

Revision numbers See page 11

#### **Equipment combinations**

Valves				Actuat	ors				
		,	•	SAX	P	sqv	P	SAV	P
		DN	H <sub>100</sub>	$\Delta p_{\text{max}}$	Δps	$\Delta p_{max}$	Δps	$\Delta p_{\text{max}}$	Δps
			[mm]	[kPa]	[kPa]	[kPa]	[kPa]	[kPa]	[kPa]
Standard	VPF43.50F16	50		600	600	600	600	-	-
flow rate	VPF43.65F24	65	20	600	600	600	600	-	-
	VPF43.80F35	80		600	600	600	600	-	-
	VPF43. 100F70	100	40	-	-	600	600	600	600
	VPF43. 125F110	125	40	-	-	600	600	600	600
	VPF43. 150F160	150	43		-	600	600	600	600

High flow	VPF43.50F25	50		600	600	600	600	-	-
rate	VPF43.65F35	65	20	600	600	600	600	-	_
	VPF43.80F45	80		600	600	600	600	-	_
	VPF43. 100F90	100		-	-	600	600	600	600
	VPF43. 125F135	125	40	-	-	600	600	600	600
	VPF43. 150F200	150	43	ı	-	600	600	600	600

 $H_{100}$  = nominal stroke

 $\Delta p_{\text{max}}$  = maximum permissible differential pressure across the valve's control path, valid for the entire actuating range of the motorized valve

 $\Delta p_s$  = maximum permissible differential pressure at which the motorized Combi valve will close securely against the pressure (close off pressure)

#### **Actuator overview**

Туре	Stock no.	Stroke	Pos. force	Operating voltage	Positioning signal	Spring return time	Spring return direction	Positioning time	LED	Manual adjuster	Extra functions
SAX31P03	S55150-A118			AC 230 V	3-position				-		1)
SAX61P03	S55150-A114	20 mm	500 N	AC/DC 24 V	DC 010 V DC 420 mA 01000 Ω	-	-	30 s	<b>✓</b>	Push and fix	2), 3)
SAX81P03	S55150-A116				3-position	-	-	30 s	-	Push and fix	1)
				_							
SQV91P30	S55150-A130	20 mm	1100 N	AC/DC 24 V	3-position	20 -	Pull to open	< 120 s <sup>5)</sup>	/	Turn and	1) 6)
SQV91P40	S55150-A131	40 mm	1100 N	AC 230 V 4)	DC 010 V DC 420 mA	30 s	or push to close <sup>5)</sup>	< 120 \$ "/	V	fix	, , ,
		1		1	T		T	Г	1	1	F
SAV31P00	S55150-A121			AC 230 V	3-position		-		-		1)
SAV61P00	S55150-A119	40 mm	1100 N	AC/DC 24 V	DC 010 V DC 420 mA 01000 Ω	-  -	-	120 s	✓	Push and fix	2), 3)
SAV81P00	S55150-A120		AC/i		3-position		-		-		1)

Optional accessories: Auxiliary switch, potentiometer


Position feedback, forced control, change of flow characteristic

Optional accessories: Auxiliary switch, sequence control, acting direction


<sup>4)</sup> Voltage adapter required, order separately

<sup>5)</sup> Selectable

<sup>6)</sup> Position feedback



1 Ring with dial for presetting




- 2 Aperture for the differential pressure controller is linked with outlet port B
- 3 Differential pressure controller
- 4 Plug with variable presetting opening
- 5 Control valve
- **6** Pressure test point (P/T) at outlet port B, blue ribbon, P-
- 7 Pressure test point (P/T) at inlet port A, red ribbon, P+
- A Inlet port A
- B Outlet port B

#### **Functional principle**

The Combi valves VPF43.. combine three functions:

- a control valve (5) for controlling the volumetric flow,
- an adjusting mechanism (1, 4) with a dial for a presettable maximum volumetric flow,
- a differential pressure controller (3) for balancing pressure fluctuations in the hydraulic system respectively across the control valve.

The mechanical series-connected differential pressure controller keeps the differential pressure  $(p_1-p_2)$  constant across the control valve and thus the set volumetric flow too. The desired maximum volumetric flow can be preset with the adjusting mechanism. The controller (not shown) and the actuator regulate the volumetric flow and consequently the desired temperature in buildings, rooms or zones.



P- = P/T port, pressure test point with blue ribbon (6)

P+ = P/T port, pressure test point with red ribbon (7)

 $p_1$  = pressure at inlet port A of Combi valve

p<sub>2</sub> = pressure at outlet port of control valve (5)

 $p_3$  = pressure at outlet port B of Combi valve

- A Inlet medium (inlet port A)
- B Outlet medium (outlet port B)
- 1 Ring with dial for presetting
- 3 Differential pressure controller
- 5 Control valve with mounted actuator

#### Medium flow

The medium entering the Combi valve (inlet port A) first passes through the control valve (5) with a linear characteristic and a stroke of 20 mm (DN 50...80) respectively 40 mm (DN 100...150). The actuator (not shown here) opens and accurately positions the control valve. Then, the medium flows through the variable presetting opening (4) which is connected to the ring with dial (1) for presetting the desired maximum volumetric flow.

Before leaving the Combi valve (outlet port B), the medium passes through a built-in mechanical differential pressure controller (3). This differential pressure controller is the heart of the Combi valve and ensures that the selected volumetric flow is maintained across the whole working range and independent of the inlet pressure  $p_1$ .

#### Pressure test points

The Combi valve VPF43.. is equipped with two pressure test points (P+, P-) for measuring and monitoring the differential pressure across the valve during commissioning. For that purpose, the electronic manometer ALE10 can be used.

#### Manual control

Manual control is only possible with mounted actuator.

#### Advantages

The advantages of Combi valves are that:

- once the flow limiter is set to design flow, the hydraulic circuit self balances, even when changes to the system are made, such as additions.
- for any heat demand the Combi valve with mounted actuator can be set to the desired volumetric flow and will be relatively constant regardless of pressure fluctuations in the system.

Constant flow regardless of pressure changes in the system reduces hydraulic interdependence and leads to a more stable control.

#### **Accessories**

Product no.	Stock no.		Beschreibung
ALE10	ALE10		Electronic manometer <b>excluding</b> measuring lines and measuring tips.  Measuring range 0 700 kPa. A differential pressure of more then 1000 kPa will destroy the pressure sensor.  For measuring the differential pressure between P+ and P- of the Combi valves (refer to diagram under "Functional principle" on page 4).  Functions of the manometer:  Start/stop  Automatic zero position  Backlit display  Display: Out → outside the measuring range  Holding function
ALE11	ALE11	9	Measuring lines and straight measuring tips for use with Siemens Combi valves.  Equipped with G 1/4" connection with 2 x 40 mm needles.
ALP46	S55264-V115	9	Blanking plugs for P/T ports Connection to valve body: G 1/4" to ISO 228, inclusive O-ring
ALP47	S55264-V116		Drain ball valve inclusive O-ring  Port: External threads G ½" to ISO 228  Connection to valve body: G ¼" to ISO 228, inclusive O-ring
ALP48	S55264-V117		Combined P/T port and drain ball valve with blue ribbon Port: External threads G 1/4" to ISO 228 Connection to valve body: G 1/4" to ISO 228, inclusive O-ring
ALP49	S55264-V118	11	Long P/T ports (set of 2 pieces) Set contains 1 piece each with a red and blue ribbon. Port: External threads G 1/4" to ISO 228 Connection to valve body: G 1/4" to ISO 228, inclusive O-ring

#### **Engineering example**

#### Basis of design

- 1. Determine heat demand Q [kW]
- 2. Determine temperature spread ΔT [K]
- 3. Calculate volumetric flow

$$\dot{V} = \frac{Q[kW] \cdot 1000}{1.163 \cdot \Delta T[K]} \left[ \frac{I}{h} \right]$$

- 4. Select suitable Combi valve VPF43..
- 5. Determine dial setting using volumetric flow/dial presetting tables, see below.

#### Example

1. Heat demand Q = 150 kW 2. Temperature spread  $\Delta T = 6 \text{ K}$ 

3. Volumetric flow

$$\dot{V} = \frac{150 \, kW \cdot 1000}{1.163 \cdot 6 \, K} = 21'654 \, l/h = 21.6 m^3 / h$$

Hint: You can also determine the volumetric flow using the valve slide rule.

4. Select Combi valve VPF43..

Ideally, Combi valves should be selected such that they operate at about 80% of their maximum flow, enabling them to deliver spare capacity, if required.

Selection: VPF43.65F24  $\Delta p_{min} = 35 \text{ kPa}$ VPF43.65F35  $\Delta p_{min} = 70 \text{ kPa}$ 

5. Determine dial setting using volumetric flow/dial presetting tables:

VPF43.65F24 Volumetric flow 21.6 m<sup>3</sup>/h

Dial setting 3.6

VPF43.65F35 Volumetric flow 21.6 m<sup>3</sup>/h

Dial setting 2.7

### Volumetric flow/dial presetting

Tables to determine the dial setting for a desired volumetric flow.

Nominal flow

#### Standard flow rate

 VPF43.50F16
 5.0F16

 [m³/h]
 2.3
 3
 3.8
 4.5
 5.3
 6
 6.8
 7.5
 8.3
 9
 9.8
 10.5
 11.3
 12
 12.8
 13.5
 14.3
 15

Free cond					-				_				_					. —			
Dial	Min.	0.2	0.4	0.6	8.0	1	1.2	1.4	1.6	1.8	2	2.2	2.4	2.6	2.8	3	3.2	3.4	3.6	3.8	4
VDE42.4	05504																		0.4	3,,	!

VPF43.65F24 24 m³/h nominal [m<sup>3</sup>/h] 4.4 5.6 7.7 8.6 9.6 10.5 11.5 12.5 13.5 14.7 15.8 17.1 18.5 21.5 23.2 25 6.6 19.9 Dial 0.4 0.6 8.0 1.2 1.4 1.6 1.8 2.2 2.4 2.6 2.8 3.2 Min. 2

VPF43.	80F35																		35 ı	m³/h no	ominal
[m <sup>3</sup> /h]				5.3	6.9	8.3	9.6	10.9	12.2	13.5	14.8	16.2	17.6	19.1	20.7	22.4	24.3	26.4	28.7	31.2	34
Dial	Min	0.2	0.4	0.6	0.8	1	12	14	16	1.8	2	22	24	26	2.8	3	3.2	34	3.6	3.8	4

VPF43.	100F70	)																	70 ı	n³/h n	ominal
[m³/h]				12.1	15	18	21	23	25	28	30	32	35	38	40	43	47	51	56	62	68
Dial	Min.	0.2	0.4	0.6	8.0	1	1.2	1.4	1.6	1.8	2	2.2	2.4	2.6	2.8	3	3.2	3.4	3.6	3.8	4

VPF43.	125F1	10																	110	m³/h n	ominal
[m³/h]				18.5	23	28	33	37	42	46	51	55	60	65	69	74	80	85	92	99	110
Dial	Min.	0.2	0.4	0.6	0.8	1	1.2	1.4	1.6	1.8	2	2.2	2.4	2.6	2.8	3	3.2	3.4	3.6	3,8	4

VPF43.	150F16	60																	160 ı	m³/h n	ominal
[m <sup>3</sup> /h]				25.6	31	38	44	51	57	63	72	76	82	89	96	104	111	120	128	137	148
Dial	Min,	0,2	0,4	0.6	8.0	1	1.2	1.4	1.6	1.8	2	2.2	2.4	2.6	2.8	3	3.2	3.4	3.6	3.8	4

#### High flow rate

VPF43.50F25	25 m <sup>3</sup> /	h nominal
VPT43.5UF25	25 III /	ii iioiiiiiai

[m <sup>3</sup> /h]				4.3	5.2	6.2	7.2	8.1	9	10	11	12.1	13.2	14.3	15.4	16.5	18.2	19.9	21.6	23.3	25
Dial	Min.	0.2	0.4	0.6	8.0	1	1.2	1.4	1.6	1.8	2	2.2	2.4	2.6	2.8	3	3.2	3.4	3.6	3.8	4

#### VPF43.65F35 35 m<sup>3</sup>/h nominal [m<sup>3</sup>/h] 7.6 10.5 11.9 13.3 14.7 16.0 17.5 19.0 20.6 22.3 24.1 26.0 28.0 30.2 32.5 35 Dial Min. 0.2 0.4 0.6 8.0 1.2 1.4 1.6 1.8 2 2.2 2.4 2.6 2.8 3 3.2 3.4 3.6 3.8 4

VPF43.	80F45																		45 ı	m³/h no	ominal
[m³/h]				7	9	11	12.8	14.5	16.2	18	19.6	21.4	23.2	25.1	27.1	29.3	31.6	34.1	36.8	39.8	43
Dial	Min	0.2	0.4	0.6	0.8	1	12	1 4	16	1.8	2	22	24	26	2.8	3	3.2	3.4	3.6	3.8	4

VPF43.	100F9	0																	90 ı	m³/h n	ominal
[m <sup>3</sup> /h]				14.8	19	22	26	29	32	35	38	42	44	48	52	56	61	66	73	81	90
Dial	Min.	0.2	0.4	0.6	8.0	1	1.2	1.4	1.6	1.8	2	2.2	2.4	2.6	2.8	3	3.2	3.4	3.6	3.8	4

VPF43.	125F1	35																	135 ו	m³/h n	ominal
[m <sup>3</sup> /h]				23	29	36	42	48	53	59	64	70	76	81	87	93	100	107	114	122	135
Dial	Min.	0.2	0.4	0.6	8.0	1	1.2	1.4	1.6	1.8	2	2.2	2.4	2.6	2.8	3	3.2	3.4	3.6	3.8	4

VPF43.	150F2	00																	200 m <sup>3</sup> /h nominal			
[m <sup>3</sup> /h]				32	40	48	57	64	72	80	88	96	104	112	121	131	141	152	165	178	195	
Dial	Min.	0.2	0.4	0.6	8.0	1	1.2	1.4	1.6	1.8	2	2.2	2.4	2.6	2.8	3	3.2	3.4	3.6	3.8	4	

#### **Engineering notes**

Valve	Symbols / Direction of flow	Flow in control mode	Valve	stem
	VPF43		retracts	extends
Combi valve	*315203	variable	closes	opens



#### The direction of flow indicated (arrow on the valve body) is mandatory!

The valves should preferably be mounted in the return pipe where temperatures are lower and where the sealing gland is less affected by strain.

#### Symbol

Symbol used in catalogs and application descriptions	Symbol used in diagrams
	There are no standard symbols for Combi valves in diagrams.

#### Recommendation

A strainer or dirt trap should be fitted upstream of the valve to enhance reliability and service life.


Remove dirt, welding beads etc. from valves and pipes.

Do not insulate the actuator bracket, as air circulation must be ensured!

#### **Mounting notes**

Combi valve and actuator can be easily assembled on site. Neither special tools nor adjustments, besides the presetting, are required. Prior to mounting the actuator, the required volumetric flow must be set. The valve is supplied with Mounting Instructions (74 319 0711 0).

#### Mounting positions




#### Installation notes

#### **Presetting**

It is recommended to mount the actuator before the presetting is made.

- 1. Mount actuator and fix valve neck coupling
- 2. Mount valve stem coupling and tighten slightly
- 3. Make presetting according to table under "Volumetric flow/dial presetting" on page 6. Do NOT adjust presetting to a dial reading lower than "0.6".
- 4. Tighten stem coupling







Using an open-end wrench and turn the stem with dial to the desired presetting

position.

#### Valve characteristic



Working pressure and medium temperature Fluids



Working pressure and medium temperature staged as per ISO 7005

 $\triangle$ 

Current local legislation must be observed.

#### Commissioning notes



The valves must be commissioned with the actuator correctly fitted. Strong pressure impacts can damage closed Combi valves.



The Combi valves have to be open when flushing or pressure testing the system. Strong pressure impacts can damage closed Combi valves.



Differential pressure  $\Delta p_{\text{max}}$  across the valve's control path is not allowed to exceed 600 kPa.

#### Manual control

Only possible with mounted actuator.

#### **Maintenance notes**

The VPF43.. Combi valves are maintenance-free.



When performing service work on the valve or actuator:

- Switch off the pump and disconnect power supply.
- Close the shut-off valves in the piping network.
- Fully reduce pressure in the piping network and allow the pipes to cool down completely.

Remove the electrical connections only if necessary.

#### Sealing gland

The stem sealing gland cannot be exchanged. In case of leakage the whole valve must be replaced.

## Disposal

Due to the different types of material used, the valve must be disassembled prior to disposal. Special handling of certain valve components may be required by law or may be sensible from an ecological point of view.

Local and currently valid legislation must be observed.

#### Warranty

Application-related technical data are guaranteed only when the valves are used in connection with the Siemens actuators listed under "Equipment combinations" on page 3.


Siemens warranty is void, if used with non-Siemens actuators.

#### **Technical data**

Functional data	PN class		PN 16 as pe	r EN 1333			
	Permissible opera	ating pressure	1600 kPa (1 EN 1333	6 bar) as per ISC	7628 /		
	Volumetric flow de	eviation	< ±10% with	in differential pre	ssure range		
	Valve characteris	tic	Linear as pe	r VDI/VDE 2173			
	Leakage rate		Class IV (0	.0.01% of volum	etric flow $\dot{V}_{100}$ )		
			to EN 1439				
	Operating direction	on	Normally op	en (push to close	e)		
	Permissible media	a	temperature with antifree	ature hot water, r hot water, chilled ze dation: Water trea	d water, water		
	Medium temperat	ture	1120 °C				
	Rangeability		1:100				
	Nominal stroke	DN 50, 65, 8 DN 100, 12 DN 19					
Standards	Pressure Equipm	ent Directive	PED 97/23/E	EC			
	Pressure Accesso	ories	As per article	e 1, section 2.1.4			
	Fluid group 2	DN 5		marking as per a ound engineering			
		DN 65, DN 15	O Category I, v	with CE-marking			
	Environmental co	mpatibility	ISO 14001 ISO 9001 SN 36350	(Environm (Quality) (Environm	•		
			RL 2002/95/	compatibl	e products)		
Materials	Valve body	DN 50-80, 12	5 Gray cast ird	on GJL-250			
		DN 100, 15	0 Nodular cas	t iron GJS-400			
	Stem, spring		Stainless ste	eel			
	Trim		Brass (DZR)				
	Regulator		Stainless ste	eel			
	Seals		EPDM				
Dimensions / weight	Dimensions		Refer to "Dir	mensions" on paເ	ge 11		
	Flange connection	ns	To ISO 7005	5-2			
	Pressure test poir	nts (P/T-ports)	G ¼ inch (co	nnection)			
			2 mm x 40 n	nm (measuring ti	ps)		
	Weight		Refer to "Dimensions" on page 11				
General ambient conditions			Operation EN 60721-3-3	Transport EN 60721-3-2	<b>Storage</b> EN 60721-3-1		
	Environmental cor	nditions	Class 3K5	Class 2K3	Class 1K3		
	Temperature		-15+55 °C	-30+65 °C	-15+50 °C		
	Humidity		595 % r.h.   < 95 % r.h.   595 % r.h.				

It is recommended to use Combi valves in plants with variable speed pumps. When sizing the pump, it must be made certain that the most critical branch or consumer in the system – usually the remotest from the pump – gets enough pressure (pump head).

#### **Dimensions**



Product	DN	В	ØD	Ø D1	Ø D2	L1	L2	L3	øк	H1	H2	ı	1	kg
number												SAXP	SQVP	
VPF43	50	16	165	99	19 (4x)	230	115	65	125	187.5	284	630	577	14
	65	17	185	118	19 (4x)	290	145	84	145	195	291,5	637	584	19.5
	80	17	200	132	19 (8x)	310	155	90.5	160	216.5	313	659	606	25
	100	20	235	156	19 (8x)	350	162	111	180	332	367	800	720	50
	125	25	270	184	19 (8x)	400	192	133	210	358	384	820	750	77
	150	26	285	211	23 (8x)	480	230	156	240	401	413	870	790	111

DN = Nominal size

H = Total actuator height plus minimum distance to the wall or the ceiling for mounting,

connection, operation, maintenance etc.

11 = Dimension from the pipe center to install the actuator (upper edge)

H2 = Valve in the «CLOSED» position means that the valve stem is fully retracted.

#### **Revision Numbers**

Product number	Valid from rev. no.	Product number	Valid from rev. no.
VPF43.50F16	A	VPF43.50F25	A
VPF43.65F24	A	VPF43.65F35	A
VPF43.80F35	A	VPF43.80F45	A
VPF43.100F70	A	VPF43.100F90	A
VPF43.125F110	A	VPF43.125F135	A
VPF43.150F160	A	VPF43.150F200	A