SIEMENS



Actuators

SQN72...

Electromotoric actuators for air dampers and control valves of oil or gas burners of small to medium capacity.

The SQN72... and this Data Sheet are intended for use by OEMs which integrate the actuators in their products!

Use	e / features	
		 The SQN7 actuators are designed for driving gas or air dampers of oil or gas burners of small to medium capacity, for load-dependent control of the fuel and the combustion air volume: In connection with P-PI or PID controllers, such as the RWF40 Directly via the different types of burner controls, such as LOA, LMO, LME, or LFL In connection with 1- or 2-wire control or 3-position controllers
•	Features:	 Impact-proof and heat-resistant plastic housings Plug terminals for the electrical connections Maintenance-free gear train (can be disengaged) Internal position indication Easy-to-adjust end and auxiliary switches for setting the switching points Integrated electronic circuits Degree of protection IP54
•	Holding torque:	0.71.3 Nm
•	Running time:	430 s
•	Direction of rotation:	counterclockwise

To avoid injury to persons, damage to property or the environment, the following warning notes should be observed!

Do not interfere with or modify the actuators!

- All activities (mounting, installation and service work, etc.) must be performed by qualified staff
- Before making wiring changes in the connection area of the actuator, completely isolate the equipment from the mains supply (all-polar disconnection)
- Ensure protection against electric shock hazard by providing adequate protection for the connection terminals and by securing the housing cover
- Each time work has been carried out (mounting, installation, service work, etc.), check to ensure that wiring is in an orderly state
- Fall or shock can adversely affect the safety functions. Such actuators must not be put into operation, even if they do not exhibit any damage

Mounting notes

• Ensure that the relevant national safety regulations are complied with

Standards and certificates

Conformity to EEC directives

Electromagnetic compatibility EMC (immunity)
 Low-voltage directive

89 / 336 / EEC 73 / 23 / EEC



ISO 9001: 2000 Cert. 00739



: 2000 ISO 14001: 2004 39 Cert. 38233

Disposal notes



The actuators contain electrical and electronic components and must not be disposed of together with domestic waste.

Local and currently valid legislation must be observed.

Mechanical design

Housing	 Made of impact-proof and heat-resistant plastic
	- The housing accommodates:
	 The reversible synchronous motor with gear train, which can be disengaged
	 The camshaft of the control section
	 The relays, depending on the type of actuator
	 The switches, connected to the terminals via the printed circuit board
	Color: Gear train housing dark-grey, cover light-grey
Drive motor	- Reversible and locking-proof synchronous motor
Coupling	 Drive shaft can be manually disengaged from the gear train and motor (by pressing pin «K») Automatic reengagement
Adjustment of	- Via adjustable cams
switching points	 Scales beside the cams indicate the angle of the switching point Assignment of cams to the end and auxiliary switches is color-coded (refer
	«Connection diagrams»)
	- Some of the cams feature fine adjustment; they can be adjusted with a standard
	 screwdriver The other cams can be adjusted manually or with the enclosed hook-spanner similar tool
Position indication	- Internally: Scale at the beginning of the camshaft on the gear train side
Electrical connections	- Refer to «Technical data»
Gear train	- Maintenance-free
Drive shaft	- Made of black-finished steel
	- Ready fitted to the front of the gear train
	- As different actuator versions available
Mounting and fixing	- Front of the gear train is used as the mounting surface

Versions for fitting potentiometer

Fitting a potentiometer

Certain types of actuators are supplied ready prepared for fitting a potentiometer. They are prepared for housing the potentiometer. Accessories are not required. The required type of potentiometer is to be ordered as a separate item (refer to «Ordering»).

Type summary (other types on request)

Diagram	Drive shaft 1)	Running time 2)	Nominal torque 4)	Holding torque	AS 5)	Relay	Pot.	Length of	Types for mains voltage /
		for 90°	(max.)				7)	housing 1)	mains frequency
	No.	S	Nm						AC 230 V 3)
				Nm	Pcs.				+10 % -15 %
No.						Pcs.		mm	5060 Hz
Actuator	Actuators SQN70 / counterclockwise rotation ⁶⁾								
А	0	4	1.5	0.7	2	2	х	117	SQN72.2A4A20
А	0	30	2.5	1.3	2	2	х	117	SQN72.6A4A20
В	0	4	1.5	0.7	2	3		117	SQN72.2B4A20
С	0	30	2,5	1,3	2		х	117	SQN72.6C4A20

Legend

1) Refer to «Dimensions»

2) Valid for 50 Hz; at 60 Hz, running times are about 20 % shorter

3) AC 230 V +10 % / -15 % possible, but in the case of undervoltage, torque is reduced by about 20 %

4) Under nominal conditions; under extreme conditions (e.g. +60 °C, AC 230 V –15 %) approx. –25 %

5) Auxiliary switches (in addition to the 2 end switches)

6) When facing the drive shaft and when control voltage is supplied to end switch I

7) Suited for direct fitting of potentiometer (refer to «Fitting a potentiometer»)

Ordering

Actuator

refer to «Type reference»

Potentiometer ASZ...

refer to Data Sheet N7921 refer to Mounting Instructions M7921 (4 319 9604 0)

Technical data

Actuator

Mains voltage	AC 230 V –15 % +10 %	
Mains frequency	5060 Hz ± 6 %	
Drive motor	synchronous motor	
Power consumption	6 VA	
Angular adjustment	max. 160°, scale range 0130°	
Mounting position	optional	
Degree of protection	IP54 to DIN 40050, when using the cable	
	entry gland provided plus plastic washers	
	for the fixing screws «M» as shown under	
	«Dimensions»	
Safety class	II to VDE 0631	
Cable entry	Rubber grommet for single cable with a	
	max. jacket dia. of 11 mm.	
	The hole in the grommet must be ade-	
	quately matched to the dia. of the jacket.	
	To ensure that the grommet will be tight,	
	the cable must be correctly laid in this area	
	(no bends); the grommet is provided	
Cable strain relief	Cable strain relief with 2 fixing screws is	
	provided	
Cable connections	2 plug-in spaces with connection terminal	
	type CUM, made by Stelvio for the following	
	types of connectors:	
	- CUF 5-4 (plug-in space X1)	
	- CUF 5-5 (plug-in space X2)	
	recommended cross-sectional area of	
	stranded wire: min. 0.5 mm ² , max. 1.5 mm ²	
Ferrules	adapted to cross-sectional area of <cf< td=""></cf<>	
Feitules	complexscriptssize="9">stranded wire	
Direction of rotation		
Nominal and holding torque	refer to «Type summary» refer to «Type summary»	
Running times	refer to «Type summary»	
Weight (average)	approx. 500 g	
On time	60 %, max. 3 min. continuous operation	
Backlash between drive motor and drive		
shaft		
- As supplied	≤ 1.2° ±0.3°	
- After 250,000 cycles	$\leq 1.2 \pm 0.3$ $\leq 1.5^{\circ} \pm 0.3^{\circ}$	
- / 1101 200,000 0y0103	2 1.0 LO.0	

End and auxilia switches

End and auxiliary	Number of end switches	2				
switches	Number of auxiliary switches	refer to «Type summary»				
	Actuation	via camshaft, color-coded cams (refer to				
		«Connection diagrams»)				
		switches with fine adjustment: II and III				
	Breaking voltage	AC 24250 V				
	Adjustment of cams					
	- Without fine adjustment	1°				
	 With fine adjustment 	infinitely				
	Max. perm. amperage at $\cos \varphi = 0.9$	Max. perm. amperage at $\cos \varphi = 0.9$				
	(values in parentheses: short-time peaks for max. 0.5 s)					
	Diagram A					
	 Terminals 1, 2, 3, 8 	0.5 A				
	– Terminal 4, 5	2 A (14 A)				
	– Terminal 6, 7	1 A (7 A)				
	Diagram B					
	– Terminals 1, 3, 8	0.5 A				
	– Terminal 4, 5	3 A (14 A)				
	– Terminal 6, 7	1 A (7 A)				
	Diagram C					
	– Terminals 1, 2, 3, 4, 5	0.5 A				
	– Terminal 6, 7, 8	1 A (7 A)				
Environmental	Storage	DIN EN 60 721-3-1				
conditions	Climatic conditions	class 1K3				
	Mechanical conditions	class 1M2				
	Temperature range	-20+60 °C				
	Humidity	< 95 % r.h.				
	Transport	DIN EN 60 721-3-2				
	Climatic conditions	class 2K2				
	Mechanical conditions	class 2M2				
	Temperature range	-50+60 °C				
	Humidity	< 95 % r.h.				
	Operation	DIN EN 60 721-3-3				
	Climatic conditions	class 3K5				
	Mechanical conditions	class 3M2				
	Temperature range	-20+60 °C				
	Humidity	< 95 % r.h.				

Condensation, formation of ice and ingress of water are not permitted!

Function

A synchronous motor drives a driveshaft with attached camshaft via a gear train. The camshaft actuates the end and the auxiliary switches. Using the associated cam, the switching position of each end and auxiliary switch can be adjusted within the working range. Some of the actuator versions are equipped with electronic modules, which perform auxiliary functions in connection with the end and auxiliary switches and external devices, such as controllers (refer to «Connection diagrams»).


Connection diagrams (examples)



All following connection diagrams show the start position as supplied: - End switch position II «Closed»


No. A \rightarrow LME22...

2-stage or modulating operation \rightarrow prepurging at nominal load position «NL»




No. B \rightarrow LOA24... / LOA25... / LOA26... / LOA28... / LOA36... / LMO24... / LMO44...

2-stage operation \rightarrow prepurging at low fire position «KL»



No. C \rightarrow LFL... / LGK16... / LAL... / LOK16...



2-stage or modulating operation \rightarrow prepurging at nominal load position «NL»

No. A I / II III / IV / V AL BV1 BV2 BV3 EK2 ION FS GP HS KL LK LP LR MM M1 M2 N NL OH OW QRB R ₽ V SA Si	Number of internal diagram (second position after the dot in the type reference) End switches Auxiliary switches Remote indication of lockout (alarm) Fuel valve stage 1 Fuel valve stage 2 Fuel valve stage 3 External remote reset button Ionization probe Flame signal Gas pressure switch Main switch Low-fire Live conductor Air damper Air damper Air damper Air damper position Air pressure switch Load controller Burner of fan motor Actuator's synchronous motor Without postpurge With postpurge Neutral conductor Nominal load Oil preheater's release contact Photoresistive flame detector Temperature or pressure controller Relay Control valve Actuator
Si	External primary fuse (as specified in the Data Sheet of the relevant burner control)
SB	Safety limiter
ST	Stage
t / T	Program times (refer to the Data Sheet of the relevant burner control)
TSA	Safety time
	Resistance
Z	Ignition transformer
CLOSED	Damper fully closed
▲	Direction of rotation OPEN
▼	Direction of rotation CLOSE


Program sequence - diagrams

- A Burner ON
- A B Startup of burner
- B C Burner operation / load control operation (modulating or 2-stage)
- C Burner OFF
- C D Overrun time D End of progra
 - End of program, burner control ready for new start

	Ш
N X X X X	000

Control signals delivered by burner control Required input signals

Permissible input signals



All drive shafts shown in end switch position II «Closed» as supplied.

MThrough-hole 5.3 mm dia.TKnockout hole 5.3 mm dia.